

Managing a leaky abandoned well: detection and advanced mitigation options (hydraulic barrier)

Arnaud Réveillère, Thomas Le Guenan, Jeremy Rohmer, Jean-Charles Manceau

▶ To cite this version:

Arnaud Réveillère, Thomas Le Guenan, Jeremy Rohmer, Jean-Charles Manceau. Managing a leaky abandoned well: detection and advanced mitigation options (hydraulic barrier). IEA-GHG 2012 Joint network meeting, Jun 2012, Santa Fe, United States. hal-00709369

HAL Id: hal-00709369 https://brgm.hal.science/hal-00709369

Submitted on 18 Jun 2012

HAL is a multi-disciplinary open access archive for the deposit and dissemination of scientific research documents, whether they are published or not. The documents may come from teaching and research institutions in France or abroad, or from public or private research centers.

L'archive ouverte pluridisciplinaire **HAL**, est destinée au dépôt et à la diffusion de documents scientifiques de niveau recherche, publiés ou non, émanant des établissements d'enseignement et de recherche français ou étrangers, des laboratoires publics ou privés.






Hydraulic barrier design and applicability for managing the risk of CO₂ leakage from deep saline aquifers

Objectives

- > In the case of leakage of CO₂ into an overlying aquifer through man-made (e.g. abandoned well) or natural (e.g. permeable fault) pathways, directly modifying the leak hydraulic properties may not be
- Used as a corrective measure, the "hydraulic barrier" relies on brine injection in the top aquifer in order to counter the driving forces of the migration (CO₂ buoyancy and injection-induced over-pressure)




Operational issues


- availability, surface piping and equipment
- Possibility of re-using an existing well
- > Time delays of drilling a new well
- Permitting and regulatory issues
- Applicable once the secondary accumulation is detected (~ 1000/10000 tons of CO₂ at 1km depth) and characterized
- Detection and characterization time

Hydraulic barrier design: $Q_0 \& \Delta t_0$ estimates

The brine injection rate Q_0 and duration Δt_0 are chosen in order to fulfill the following requirements:


- > Rapidity: The duration necessary for stopping the leak should be as short as possible.
- Integrity (mechanical): Simple conservative analytical model of the tensile failure in the caprock in order to determine the maximum overpressure ΔP_{max}
- **Efficiency:** $\Delta P_{L+,min}(t) \leq \Delta P_{L+}(t)$, where $\Delta P_{L+,min}$ is the pressure build-up over the leak necessary for preventing the leakage due to the pressurized storage aquifer and to the CO₂ buoyancy (determined for the considered leakage scenario). ΔP_{L+} is the overpressure induced by the brine injection over the leak, estimated using the analytical Theis solution.






Numerical model

- Large scale multiphase flow transport simulation using TOUGH2 code
- > two horizontal and homogeneous 78 × 78 km aquifer layers are connected by a 170 m high vertical conduit
- > exponential grid refinements down to a 0,8m x 1,6 m grid block section for the leak
- > 100 thick storage layer (gravity neglected); 3x10m thick overlying aquifer
- > 3 Mt/y CO₂ injection
- > Homogeneous petrophysical properties typical




Leakage modeling


- Leakage detection at 10 years
- > CO₂ injection is stopped
- > Secondary accumulation: 13.8 kt of CO₂ (detectable through seismic survey), 18% only is dissolved




Hydraulic barrier modeling and results

Simulated hydraulic barriers cases and comparison of the duration necessary for stopping the leakage







Conclusions

- This methodology proposes some clear criteria for setting the main parameters of the hydraulic barrier. This remediation option can then be with balanced other possible strategies.
- > The time necessary for stopping the leakage are in good agreement with those obtained through 3D numerical simulation.
- > From the analytical results:

A leakage into a high transmissivity aquifer increases the necessary brine injection rate

Brine must be injected in the vicinity of the secondary accumulation